



ADTECH
 Analog-Digital Technology, Inc.
 95 MT. READ BLVD
 ROCHESTER, NY 14611
 PHONE: 585-698-1845
 EMAIL: INFO@ADTECH-INST.COM

TCT 326L

Three-Wire Isolated Thermocouple Transmitter

Instruction Manual

Low Power

1.0 INTRODUCTION

These instructions refer to the above model. Supplementary sheets are attached if the unit has special options or features. For detailed specifications, see page 4 or refer to the Data Bulletin. All ADTECH instruments are factory calibrated and supplied with a label detailing the calibration. Adjustments are normally not necessary. A simple calibration should be performed to verify calibration before installation.

2.0 GENERAL DESCRIPTION

The ADTECH Model TCT 326L Low Power Isolated Three-Wire Thermocouple Transmitter provides high accuracy conversion of ISA type J, K, T, E, R, S and B thermocouples and mv to a standard 4-20 ma dc process signal such as 1-5 VDC or 0-5 VDC.

This model consumes very low power, typically 3.5 mA dc and is specially designed for remote battery or solar-panel-powered applications.

The TCT 326L provides 600 volts ac or 1000 volts dc isolation from the input to output/power supply.

The primary features of the TCT 326L are:

- Low operating power, 3.5 mA typical.
- Wide range—covers the full range of ISA standard thermocouples and mv.
- Fieldadjustable via plugin jumpers and potentiometers.
- Zero suppression of up to 100% of the major range with a 16 position switch.
- High accuracy, repeatability, and ambient temperature effect stability.
- RFI Resistant.
- NO INTERACTION of zero and span controls.
- Small size—DIN mounting package provides. Only 1" w x 3.1" h x 3.6" d.

3.0 INSTALLATION

The instrument is supplied in a non-metallic general purpose DIN rail mount enclosure as standard. NEMA 4, 7 or 12 enclosures are optionally available. Installation area/location must agree with the supplied instruments including operating temperature and ambient conditions. For detailed mounting and installation information refer to page 4 inside.

Electrical Connections

The wire used to connect the instrument to the control system **Input / Output** should be twisted pair(s) and sized according to normal practice. Shielded cable is not normally necessary (if used, the shield must be grounded at the negative input of the ADTECH instrument and left floating at the sensor).

A six position compression terminal block is provided for the I/O and power connections. A housing ground terminal is not

required due to non-metallic housing.

Controls

Instrument controls consist of the following:

- Two 16 position switches for **COARSE ZERO** and **COARSE SPAN** control.
- One 4 position jumper for selection of thermocouple and major range.
- Two multiturn potentiometers; **FINE ZERO** and **SPAN** controls.
- One 2-position jumper for 20 mv elevation.
- One 4-position jumper for TC-type.


The FINE ZERO and SPAN controls are accessible through the front of the instrument.

4.0 MAINTENANCE

These instruments are electronic and require no maintenance except periodic cleaning and calibration verification. If the unit appears to be mis-operating, it should be checked as installed per section 6.0 or removed for a bench check per sections 6.0 and 7.0. MOST problems are traced to field wiring and / or associated circuits. If the problem appears to be with the instrument, proceed to sections 6.0 and 7.0.

5.0 CONNECTIONS

Standard connections are shown below and on the instrument face plate, Data Bulletin or on attached supplementary sheets.



NOTE 1: Terminal #3 should not have any customer connections.

6.0 CONFIGURATION

All ADTECH units are factory calibrated per P.O. instructions. Usually, a complete recalibration is not required unless you want to change input type, output type, or the range of the unit. A calibration sticker located on the unit identifies the model, calibration and options present. If recalibration to the same range is required, proceed to section 6.1 directly.


For new range:

- A. Open the case to gain access to the unit's pc boards. The larger pc board is the input pcb and the smaller pc board is the output/power.
- B. To determine the MAJOR RANGE setting calculate:
 1. Input Span (mV) = millivolts full scale – millivolts zero scale.
 2. Input Zero (mV) = millivolts zero scale.
 3. The Major range is the number from Table 1 that is just larger (in magnitude) of the two calculations above. Set the jumper in Table 1 to the major range determined.
- C. If the input range includes readings below 0°C (32°F) you must set the Input Zero Control for 20 mV elevation, otherwise set it to 0mV elevation. See Table 2 for the jumper setting.
- D. Select the TC burnout action from Table 3.
- E. Select the TC type from Table 4.
- F. Select the output zero from table 6

6.1 CALIBRATION

To perform a calibration check or re-calibration of the instrument, follow this procedure.

- A. Make sure the unit I / O wiring is properly connected and that the correct power source per the label is also connected. The instrument must be at normal power for a minimum of 2 minutes before proceeding to B.
- B. The input signal source must be adjustable from 0 to 100% in steps of 10% or at least 25%. The source should be either precalibrated or an accurate meter must be used to monitor the input. The input signal needs to conform to an acceptable method of simulating a thermocouple signal.
- C. The output may be monitored as a current or as a voltage across a resistor shunt, e.g. 1-5 vdc across 250 ohms.
- D. Set J1 - positions A through D - to the desired thermocouple setting (see section 8). Set the desired burnout action (J5 - to A or B) and the major range (J1 - positions A to D). If you are measuring negative



Typical Test Connection

temperatures, you may need to set J3 - position A or B elevate the signal by 20 mv.

- E. Apply an input corresponding to the zero input temperature. Rotate the **FINE ZERO** control fully counterclockwise. Rotate the **COARSE ZERO** switch(SW1) to a position where the zero level just goes above 4.00 ma output. Rotate the **COARSE ZERO** switch back one number less than the previous position (but not less than zero).
- F. With the input set at the zero input, adjust the **fine ZERO** control for 4.00 ma to the desired accuracy.
- G. Apply an input corresponding to the full scale input temperature. Turn the **FINE SPAN** control fully counterclockwise. Turn the **COURSE SPAN** switch(SW2) to a position where the output just exceeds 20.00 ma output. Turn the switch back one number less (but not less than 0).
- H. With the input set to the full scale input, adjust the fine span control for 20.00 ma to the desired accuracy.
- I. Repeat steps F and H until the readings remain within to desired calibration accuracy.
- J. Check the instrument at the 25-50-75% input settings minimum.

7.0 FIELD TROUBLE SHOOTING GUIDE (300L Series)

This section offers a simple, first level trouble-shooting aid for an apparent instrument malfunction.

| SYMPTOM | CORRECTIVE ACTION |
|-----------|---|
| No output | <ol style="list-style-type: none"> 1. Check the input and output connections carefully. 2. Check that the power supply polarity is correct and that the output loop power is present on the indicated terminals. 3. Check that the input source(s) is correct and that it changes magnitude between zero and full scale values when so adjusted. 4. Make sure the output load is over kΩ and that the correct meter range is selected. <p>All external checks are complete. Problem seems to be internal.</p> |

Troubleshooting beyond the above may be difficult without special equipment. We do not recommend attempting repair of the unit in the field. ADTECH offers a very responsive repair policy.

TABLE 6

| Output Range | |
|--------------|------|
| 1-5 vdc | J6-A |
| 0-5 vdc | J6-B |

8.0 TABLES, OUTLINE / MOUNTING

**TABLE 1
MAJOR RANGE**

| | |
|----------|------|
| 10mV | J2-B |
| 30mV | J2-A |
| 100 mV | J2-D |
| Reserved | J2-C |

| | |
|------------|------|
| Up Scale | J5-A |
| Down Scale | J5-B |

**TABLE 2
INPUT ZERO
ELEVATION CONTROL**



| | |
|------|------|
| 20mV | J3-A |
| 0mV | J3-B |

**TABLE 4
TC TYPE**

| | |
|------|--------|
| E | J1-A |
| J | J1-B |
| T, K | J1-C |
| R, S | J1-D |
| B | J1-Out |

Note: Table 5 not required. Table 6 on page 2.

8.1 PCB LAYOUT



9.0 SPECIFICATIONS

INPUT/OUTPUT

INPUT SIGNALS

- Thermocouple and mv, all standard ISA Calibration (B, E, J, K, R, S, T), -20 mv to 100 mv spans (Z in greater than 1 megohm)
- Zero Suppression: up to 100% of the major range selected in 16 divisions of the coarse zero adjustment switch.
- Span: from 0.5 mv to 100 mv full scale—switch selectable. The coarse span switch adds 16 divisions to each major range.
- Upscale/Downscale Burnout Protection: standard Burnout current: 0.1 micro amperes—nominal

OUTPUT SIGNALS

0-5 VDC, 1-5 VDC

OUTPUT LOAD (RL) = 10k Ω min.

PERFORMANCE

- Calibrated Accuracy: $\pm 0.1\%$ (of mv input)
- Independent Linearity: $\pm 0.01\%$ maximum, $\pm 0.006\%$ typical (14 bit digital linearity)
- Repeatability: $\pm 0.005\%$ maximum; $\pm 0.002\%$ typical
- Zero TC: $\pm \left(\frac{.025}{\text{input span (MV)}} + 0.007 \right) \% \text{ of span max}/^\circ\text{C}$
- Span TC: $\pm 0.008\%$ of span max/ $^\circ\text{C}$
- Load Effect: $\pm 0.005\%$ zero to full load
- Output Ripple: 10 mv P/P maximum
- Response Time: 110 milliseconds (10 to 90% step response)
- Bandwidth: (-3 db): 3.2 Hz
- Temperature Range: -25 $^\circ$ to 185 $^\circ$ F (-31 $^\circ$ to 85 $^\circ$ C) operating
-40 $^\circ$ to 200 $^\circ$ F (-40 $^\circ$ to 93 $^\circ$ C) storage

- Power Supply Effect: $\pm 0.005\%$ over operating range
 - Isolation: Input/output/case: 1000 vdc or 600 vac
 - Cold Junction Compensation Error: 1.5 $^\circ$ C max (0 $^\circ$ to 50 $^\circ$ C)
 - Burnout Current: 0.1 micro amperes—nominal
- Note: All accuracies are given as a percentage of span

POWER

- 7 to 42 vdc, 3.5 mA typical, 5 mA max.

MECHANICAL

- Electrical Classification: General purpose
- Connection: Screw, compression type, accepts up to 14 AWG
- Controls: Refer to page 1
- Mounting: DIN, Surface, Snap-Track, or NEMA 4 or 7
- Weight: Net Unit: 4 oz. (115 grams)
Shipping: Nominal 7 oz. (200 grams)

OPTIONS

| Option Number | Description |
|-------------------|-------------|
| H 15D, H 25 - H30 | Mounting |

10.0 OUTLINE & MOUNTING

